



Access Point location reference tag  
(see AP tag table and AP ID coding table for code mappings)



Internal omnidirectional antenna – ceiling mount



External patch antenna – outward facing – wall / beam /column mount



External patch antenna – downward facing



Highly directional external antenna – outward facing – wall / beam /column mount



Highly directional external antenna – downward facing



Internal omnidirectional antenna – 90 deg. wall mount bracket



Internal omnidirectional antenna – wall plate surface mount

### AP tag table – AP types

- Y001: Cisco 1121g
- Y002: Cisco 1252
- Y003: Cisco 1142
- Y003: Cisco 3602i
- Y004: Cisco 3702i
- Y005: Cisco 3702e + AIR-ANT2566-P4W-R
- Y006: Cisco 702W
- Y007: Cisco 2602i
- Y008: Cisco 3702e + AIR-ANT2566-D4M-R
- Y009: Cisco 3702p + AIR-ANT2513-P4M-N
- Y010: Cisco 3702e + AIR-ANT2544-V4M-R
- Y011: Cisco 3802i
- Y012: Cisco 3802e + AIR-ANT2566-P4W-R
- Y013: Cisco 3802e + AIR-ANT2566-D4M-R
- Y014: Cisco 1810w

### AP ID coding (fff-nnn)

fff : floor/level of AP installation (where ground level is 1, 2<sup>nd</sup> floor is 2, basement is B, sub-basement is B2, etc.)

nnn : AP number on floor (numbering starts at 001 on each floor)

	REVISION:	PROJECT NAME:	DRAWN BY:	PROJECT #:
	1	UIT – Infrastructure Planning	ER	
	2	Standards	APPROVED BY:	ISSUE #: 1
	3		ER	
	4	DRAWING NAME:	DATE:	DRAWING #:
5	Wi-Fi Symbols	Sept. 28, 2016	UIT-IPA-02	
			SCALE:	
			NTS	